

Items & quantities	1/4"	3/8"	1/2"
1 – M3 MCL Hanger (includes 1/4"-20 cut screw)	MM325 MM325T	MM338 – cULus MM338T – cULus	MM350 – cULus MM350T – cULus
1 – All thread rod	1/4" – 20	3/8" – 16	1/2" - 13
2 – Hex nuts	1/4" – 20	3/8" – 16	1/2" - 13
1 – Heavy Duty washer	10+ gauge x 2.5" diameter		

How to install:

1. Take all thread rod and thread up through the hanger enough to secure a hex nut onto the top of the hanger.
2. Where you want to put the hanger, hold all thread rod and push hanger up through the center gap of the bottom chord until the hanger goes through. Rotate 90° and drop hanger back down on the chord.
 Note: For Unistrut hold the hanger and drop the all-thread rod through the elongated slot, resting the hanger on top.
3. Tighten 1/4"-20 cut screw against outer side of bottom chord or Unistrut.
4. Slide heavy duty washer onto the threaded rod and hold in place while threading a hex nut onto the rod. Finger-tighten so that tension on washer secures the hanger assembly in place.
5. Torque cut screw and nuts: 60 lb inch or 6-8 NW. If torque wrench is not available, use a wrench tighten hex nut 1/2 to 1 full turn.